

AD-4430B DIN Rail Weighing Module with BCD Output

Simplified Instruction Manual

Refer to the instruction manual on the A&D home page
URL: <http://www.aandd.co.jp/>

1WMPD4002677D

This Manual

- This manual describes how the product works and how to get the most out of it in terms of performance. Read this manual thoroughly before using the product and keep it at hand for future reference.
- Product specifications are subject to change without any obligation on the part of the manufacturer to notify of changes.
- This manual is subject to change without notice at any time to improve the product. No part of this manual may be photocopied, reproduced, or translated into another language without the prior written consent of the A&D Company, limited.
- Do not attempt to repair, modify or disassemble the product. Doing so will void the warranty.

©2018 A&D Company, Limited All rights reserved.
3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170-0013, JAPAN
Telephone: [81] (3) 5391-6132 Fax: [81] (3) 5391-6148.

1. Cautions

1.1. Installation and Precautions

Before use, confirm the following articles for safe operation.

- Avoid vibration, shock, extremely high temperature and humidity, direct sunlight, dust, splashing water, air containing salt or corrosive gases, places where inflammable gases are present.
- The operating temperature is -10°C to +50°C (14°F to 122°F).
- Ground the module.
- Keep cables away from power cables and other sources of electrical noise. Use a stable DC24 V power source that does not include step down voltage and noise.
- Do not share the earth ground line and power line with other electrical power equipment.
- When extending the load cell cable, separate it from the power cable and electrical cables with much noise.
- Do not turn on the module until installation is complete. The module is not equipped with a switch to turn off.
- After the installation is complete, take off the protective cover prior to turning on the AD-4430B.
- Use a shielded load cell cable.
- Do not connect more sensors than the allowable number noted in the specifications.

1.2. Cautions During Use


The AD-4430B is a precision instrument that measures microvolt output from load cell. Prevent noise sources such as power lines, radios, electric welders or motors from affecting the instrument.

- Do not disassemble the AD-4430B.


2. General Specifications

Voltage requirement	DC 24 V +10%, -15%
Power requirement	6 W Max.
Load cell excitation voltage	5V 350 Ω sensor. Up to four sensors can be connected.
Operating conditions	-10 °C to +50 °C, Max 85 %RH (no condensation)
External dimensions	35.3 × 110.0 × 101.3 mm (W×H×D)
Mass	Approximately 180 g
Main display	The monitor displays measurement data and settings with 7 segments of 5 digits and negative sign. The decimal point is specified at the function table.
Accessory	Power connector FMC 1.5/2-ST-3.5

3. External Dimensions



4. Panels



4.1. Power Supply Connector


+24 V	DC +24 V terminal.
0 V	DC 0 V terminal.

4.2. Sensor Terminals Of Load Cell

SIG-	The (-) input terminal of signal that is outputted from load cell.
SIG+	The (+) input terminal of signal that is outputted from load cell.
EXC-	The (-) output terminal to load cell excitation voltage (-).
SEN-	The (-) input terminal for sensing input (-). (When performing the 4-wire connection, connect between EXC- and SEN-.)
SEN+	The (+) input terminal for sensing input (+). (When performing the 4-wire connection, connect between EXC+ and SEN+.)
EXC+	The (+) output terminal for load cell excitation voltage (+).
SHLD	Connect shield of load cell cable.

Connections

When connecting and removing the cables, push the buttons with a driver etc. We recommend use of pole crimp terminals for the tips of cables.



4.3. BCD Connector

The circuit of BCD is isolated from the D.C. power supply and load cell circuit.
Supply D.C. +24 V between BCD PWR+24V terminal and COM terminal.

INPUT				OUTPUT
ZERO	36	18	GRS/NET	
TARE	35	17	SELECT	
HOLD	34	16	DIAGNOS	
SELECT	33	15	100	
HOLD	32	14	200	
NET DISP	31	13	400	
OVER	30	12	800	
MINUS	29	11	1000	
1	28	10	2000	
2	27	9	4000	
4	26	8	8000	
8	25	7	10000	
10	24	6	20000	
20	23	5	40000	
40	22	4	80000	
80	21	3	STROBE	
BCD PWR +24V	20	2	COM	
	19	1		

4.4. Status Indicator

LED	Meaning
G	Gross : LED lights when indicating gross value.
N	Net : LED lights when indicating net value.
H	Hold : LED lights when the hold function operates.
S	Stable : LED lights when the current weighing value is stable.
Z	Zero : LED lights when the weighing value is center zero.
X	This LED works by selected function at F.n.04.

4.5. Key switches

Operation	Function
[F]	The display switch between gross and net in factory setting.
[→]	"The zero key" to perform the zero adjustment in weighing mode. The key to change a selected item or move a flashed figure.
[↑]	"The tare key" that displays zero for net weighing. The key to select parameter or increase number in setting mode..
[ENT]	Press the key to turn on the display in standby (OFF mode). Press and hold the key to turn off the display in weighing mode. In the setting mode, this key to store new settings. "the enter key".
[ESC]	Function key can be selected the function and use in weighing mode. The return key or "the escape key" in setting mode.
[ENT] + [F]	Proceeds to function mode in weighing mode.
[→] + [ENT]	Proceeds to check mode in the function mode.
[F] + [ENT]	Proceeds to calibration in standby (OFF mode).

4.6. Operation Mode

- Function mode (In weighing mode, [ENT] + [F])
The condition of the AD-4430B can be updated and be stored.
- Check mode (In function mode, [→] + [ENT])
The mode to check the AD-4430B.
- Calibration mode (When display is turned off, [F] + [ENT])
The mode to calibrate zero point and span of the AD-4430B using span mass.

5. Calibration

The AD-4430B measures the voltage of the load cell and displays it. Calibration is the function used to adjust the AD-4430B so that the signal from the load cell is properly converted to mass. Specify decimal point (C.F.02), minimum division (C.F.03) and weighing capacity (C.F.04) in function mode.

"input voltage at zero calibration (C.F.1?), "input voltage at span calibration (C.F.1:3)" and "mass value against input voltage at span calibration (C.F.1:3)" can be changed by the "span calibration using mass (C.F.5E4)" in calibration mode. These items can be also inputted using "digital span" in function mode.

- Perform stable measurement in the calibration to prevent measurement error.
- During a stable measurement, the S LED lights.
- The decimal point flashes in calibration mode.

5.1. Span Calibration using Mass

Preset a unit, decimal point, minimum division and weighing capacity in function mode. The span calibration is performed using mass of the weighing capacity.

- When [C.F.02] and a number are displayed, an error has occurred. Refer to "Calibration Errors" for details.
- The flashing decimal point means "no weighing value".
- Before the calibration, turn on the AD-4430B more than 10 minutes so as to avoid temperature drift (change).


- When turning off the display, press and hold the [F] key and press the [ENT] key ([F] + [ENT] key). Then [C.F.02] of calibration mode is displayed.
- Press the [ENT] key to enter calibration mode. [C.F.5E4] is displayed. When returning to weighing mode, press the [ESC] key.

5.1.1. Zero Calibration

- Press the [ENT] key to display [C.F.02]. When skipping zero calibration, press the [↑] key and proceed to step 5.
- Confirm that the [S] LED is lit and press the [ENT] key. Then [.....] is displayed for 2 seconds. When canceling span calibration and returning to weighing mode, press the [ESC] key twice.

5.1.2. Span Calibration

- When [C.F.5Pn] is displayed, press the [ENT] key. The current span mass is displayed. A figure for the mass flashes. Specify a new value for the mass using the [→] and [↑] keys. When canceling span calibration and returning to weighing mode, press the [ESC] key twice.
- Place the mass on the weighing pan. Confirm that the [S] LED is lit and press the [ENT] key. Then [.....] is displayed for 2 seconds.
- When [C.F.0nd] is displayed, remove the mass from the weighing pan. When repeating span calibration, press the [↑] key.
- Press the [ESC] key. Then [C.F.5E4] is displayed and calibration data is stored in the nonvolatile memory of the AD-4430B.
- Press the [ESC] key to return to weighing mode.




5.2. Calibration Errors

Display	Cause	Treatment
C.F.01	Resolution (Weighing capacity / minimum division) exceeds the limitation.	Make the minimum division greater or make the weighing capacity smaller. The specified value depends on specifications of the weighing system.
C.F.02	The voltage in zero calibration is too large.	Check the load cell rating and connection. When nothing is wrong with the rating and connection, adjust the load cell output. When the load cell or A/D converter may be the cause of error, confirm this by using the check mode.
C.F.03	The voltage in zero calibration is too small.	Check the load cell rating and connection. When nothing is wrong with the rating and connection, adjust the load cell output. When the load cell or A/D converter may be the cause of error, confirm this by using the check mode.
C.F.04	Mass value exceeds the weighing capacity.	Use an appropriate calibration weight and calibrate again.
C.F.05	Mass value is too light for calibration.	Use an appropriate calibration weight and calibrate again.
C.F.06	Sensitivity of the load cell is too small.	Use a load cell with higher sensitivity or make the minimum division greater.
C.F.07	The polarity of the load cell output is reversed.	Check the load cell connection.
C.F.08	The output of the weighing capacity is out of range.	Use a load cell with a greater rating or make the weighing capacity smaller.

5.3. Digital Linearization (L_{nr})

- Digital linearization is the non-linearity compensation function that can rectify or reduce linearity deviation between zero point and weighing capacity.
- Up to four points can be specified except zero. (Refer to L_{nr} 0)
 - Relationship of points : Zero = L_{nr} 0 < L_{nr} 1 < L_{nr} 2 < L_{nr} 3 < L_{nr} 4
 - The high-order correction curve is used so that zero point and individual points are arranged in a straight line.
 - Digital linearization includes span calibration.
 - When [E] and a number are displayed, an error has occurred. Refer to "Calibration Error" for details.
 - A flashing decimal point means "no weighing value".
 - Before calibration, turn on the AD4430B more than 10 minutes so as to avoid temperature drift (change).

- Step 1** When turning off the display, press and hold the [F] key and press the [ENT] key ([F] + [ENT] key). Then [L_{nr} 0] of calibration mode is displayed. Press the [ENT] key to display [L_{nr} 0].
- Step 2** Press the [↑] key to select [L_{nr} 0] and press the [ENT] key to enter digital linearization.
- Step 3** [L_{nr} 0] of the zero point is displayed.
- Step 4** Place nothing on the pan. While [S] LED is displayed, press the [ENT] key to store the weighing value. Then [.....] is displayed for 2 seconds.
- Step 5** When displaying [L_{nr} 1], press the [ENT] key to select a mass value. Specify it using the [→] and [↑] key.
- Step 6** Place the mass on the pan. While [S] LED is displayed, press the [ENT] key to store the weighing value. Then [.....] is displayed for 2 seconds.
- Step 7** [L_{nr} 2] is displayed. Repeat the same operation as Step 5 and Step 6 at the second point.
- Step 8** [L_{nr} 3] is displayed. Repeat the same operation as Step 5 and Step 6 at the third point.
- Step 9** [L_{nr} 4] is displayed. Repeat the same operation as Step 5 and Step 6 at the fourth point.
- Step 10** [L_{nr} 0] is displayed. Press the [ESC] key to store new parameters into FRAM and display [L_{nr} 0].
- Step 11** Press the [ESC] key to return to weighing mode. Remove all of mass from the pan.



6.2.2. Parameters Selection And Digital Parameters

- [P] Type of parameter selection (all figures flashing)
 - [↑] Selects a parameter.
 - [ENT] Activates (store) parameter and returns to select mode.
 - [ESC] Deactivates parameter and returns to select mode.
- [D] The type to change value (figure flashing)
 - [→] Moves the flashing figure.
 - [↑] Changes the value of the flashing figure.
 - [ENT] Activates (store) value and returns to select mode.
 - [ESC] Deactivates value and returns to select mode.

6.3. Function Table

- Decimal point depends on [L_{nr} 0].
- The input voltage of the zero point ([L_{nr} 1]), the span input voltage ([L_{nr} 2]), mass for span input voltage ([L_{nr} 3]) are revised in calibration mode.
- If pressing the [→] key while displaying the digital filter ([F_{nc} 05]), the current weighing value can be monitored. Press the [→] key again to return function mode.

6.3.1. Calibration Function (L_{nr})

Item Range	Item Name	Descriptions	Default Type
[L _{nr} 0] 0 to 0.0000	Decimal point position	Decimal point position of value. 0 0.0 0.00 0.000 0.0000	0 [P]
[L _{nr} 1] 1 to 50	Minimum division (A scale / digit)	Minimum division of value. 1 2 5 10 20 50	1 [P]
[L _{nr} 2] 1 to 99999	Weighing capacity	Measurement can be displayed up to +8 digits (8 scales) from capacity. Decimal point depends on [L _{nr} 0].	70000 [D]
[L _{nr} 3] 0 to 100	Zero range	The range that the [→] key (zero key) works. Deviation from the calibrated zero point [%].	2 [D]
[L _{nr} 4] 0.0 to 5.0	Zero tracking time	Used with [L _{nr} 3] for zero tracking [sec.]	0.0 [D]
[L _{nr} 5] 0.0 to 9.9	Zero tracking width	Used with [L _{nr} 3] for zero tracking [digit]	0.0 [D]
[L _{nr} 6] 0.0 to 9.9	Stability detection time	Used with [L _{nr} 3] for stability detection [sec.]	1.0 [D]
[L _{nr} 7] 0 to 9	Stability detection width	Used with [L _{nr} 3] for stability detection [digit]	2 [P]
[L _{nr} 8] 0 to 1	Tare and zero adjustment when unstable	The adjustment when value is unstable. 0: Disables both functions. 1: Enables both functions.	1 [P]
[L _{nr} 9] 0 to 1	Tare when the gross weight is negative	Tare when the gross weight is negative. 0: Disables tare. 1: Enables tare.	1 [P]
[L _{nr} 10] 0 to 1	Output when overflow and unstable	Serial output when overflow and unstable. 0: Disables output. 1: Enables output.	1 [P]
[L _{nr} 11] 1 to 3	Exceeding negative gross weight	Judgment when the negative gross is exceeded. 1: Gross < -99999 2: Gross < -capacity 3: Gross < -19 digit	1 [P]
[L _{nr} 12] 1 to 2	Exceeding negative net weight	Judgment when the negative net is exceeded. 1: Net < -99999 2: Net < -Capacity	1 [P]
[L _{nr} 13] 0 to 1	Clear the zero value	Select to clear the zero value. 0: Disable 1: Enable	1 [P]
[L _{nr} 14] 0 to 1	Zero setting when power is turned on	When turning power on, 0: Disable 1: Enable	0 [P]
[L _{nr} 15] -7.0000 to 7.0000	Input voltage at zero	Input voltage of the zero point [mV/V]	0.0000 [D]
[L _{nr} 16] 0.0001 to 9.9999	Input voltage at span	Input voltage of the full scale [mV/V]	3.2000 [D]
[L _{nr} 17] 1 to 99999	Calibration weight corresponding to input voltage at span	Mass value to equivalent to span input voltage. ([L _{nr} 16]) Decimal point depends on [L _{nr} 0].	32000 [D]
[L _{nr} 18] 9.7500 to 9.8500	Gravity acceleration of place of calibration	Gravity acceleration of the place where calibrating the module. [m/s ²]	9.8000 [D]
[L _{nr} 19] 9.7500 to 9.8500	Gravity acceleration of place of use	Gravity acceleration of the place where using the module. [m/s ²]	9.8000 [D]
[L _{nr} 20] 0 to 1	Disable hold	0: Enable 1: Disable	0 [P]

6. Function Mode (Function List)

The function mode stores parameters to control the weighing module. The parameters are stored even without power supplied.

6.1. Outline

- Types of Functions
 - [L_{nr}] Calibration function
 - [L_{nr}] Linearity adjustment function
 - [F_{nc}] Basics function
 - [H_{ld}] Hold function
 - [B_{cd}] BCD output function

6.2. Operation

6.2.1. Select Modes Under Function Mode

- [↑] Selects a type of select mode (3 upper figures)
- [ENT] Enters a selected mode.
- [↑] Selects an item under the selected mode (2 lower figures)
- [ENT] Enters the item.
- [ESC] Stores parameters and returns to weighing mode.

6.3.2. Linearity Adjustment Function (L_{nr})

Item Range	Item Name	Descriptions	Default Type
[L _{nr} 0] 0 to 5	Number of input points	Number of adjustment point. If 0, 1 or 2 is selected, digital linearization is not used.	0 [P]
[L _{nr} 1] 7.0000 to 7.0000	Linear-zero	Input voltage for linear-zero input. [mV/V]	0.0000 [D]
[L _{nr} 2] 0 to 99999	Linear 1 Mass value	The mass value for linear 1 input. Decimal point depends on [L _{nr} 0].	0 [D]
[L _{nr} 3] 0.0000 to 9.9999	Linear 1 Span voltage	The span voltage between linear-zero and linear 1 input. [mV/V]	0.0000 [D]
[L _{nr} 4] 0 to 99999	Linear 2 Mass value	The mass value for linear 2 input. Decimal point depends on [L _{nr} 0].	0 [D]
[L _{nr} 5] 0.0000 to 9.9999	Linear 2 Span voltage	The span voltage between linear-zero and linear 2 input. [mV/V]	0.0000 [D]
[L _{nr} 6] 0 to 99999	Linear 3 Mass value	The mass value for linear 3 input. Decimal point depends on [L _{nr} 0].	0 [D]
[L _{nr} 7] 0.0000 to 9.9999	Linear 3 Span voltage	The span voltage between linear-zero and linear 3 input. [mV/V]	0.0000 [D]
[L _{nr} 8] 0 to 99999	Linear 4 Mass value	The mass value for linear 4 input (Full scale). Decimal point depends on [L _{nr} 0].	0 [D]
[L _{nr} 9] 0.0000 to 9.9999	Linear 4 Span voltage	The span voltage between linear-zero and linear 4 input (Full scale). [mV/V]	0.0000 [D]

6.3.3. Basic Function (F_{nc})

Item Range	Item Name	Descriptions	Default Type
[F _{nc} 0] 0000 to 1111	Key switch disable	Figure corresponds to each key (switch). These are enabled at weighing mode. Figure 4 fig. 3 fig. 2 fig. 1 fig. Parameter 0: Enable 1: Disable	0000 Binary number [D]
[F _{nc} 1] 0 to 7	[F] key function	0: None 4: Momentary switch 1: Print command 5: Display exchange 2: Hold 6: Tare clear 3: Alternative switch 7: Zero clear (depends on [L _{nr} 15])	5 [P]
[F _{nc} 2] 5 to 20	Display refresh rate	20 times/s 10 times/s 5 times/s	20 [P]
[F _{nc} 3] 0 to 9	X display	0: None 1: Zero tracking in progress 2: Alarm (Zero range setting error, over) 3: [F] key status 4: Zero band 5: HI output (Over the upper limit value) 6: OK output (Between upper and lower limit values) 7: LO output (Below the lower limit value) 8: User input 1 9: User output 1	0 [P]
[F _{nc} 4] 0 to 16	Digital filter	Selects a cutoff frequency. 0: None 6: 20.0 Hz 12: 2.8 Hz 1: 100.0 Hz 7: 14.0 Hz 13: 2.0 Hz 2: 70.0 Hz 8: 10.0 Hz 14: 1.4 Hz 3: 56.0 Hz 9: 7.0 Hz 15: 1.0 Hz 4: 40.0 Hz 10: 5.6 Hz 16: 0.7 Hz 5: 28.0 Hz 11: 4.0 Hz	15 [P]
[F _{nc} 5] 1 to 3	Hold function	1: Hold immediately 2: Peak hold 3: Averaging hold	1 [P]
[F _{nc} 6] -99999 to 99999	Near-zero	The reference value for near-zero. Decimal point depends on [L _{nr} 0].	10 [D]
[F _{nc} 7] 1 to 2	Comparison mass at near-zero	1: Gross weight 2: Net weight	1 [P]
[F _{nc} 8] -99999 to 99999	Upper limit value	Reference value for the upper limit. Decimal point depends on [L _{nr} 0].	10 [D]
[F _{nc} 9] -99999 to 99999	Lower limit value	Reference value for the lower limit. Decimal point depends on [L _{nr} 0].	-10 [D]
[F _{nc} 10] 1 to 2	Comparison mass of upper and lower limit	1: Gross weight 2: Net weight	1 [P]
[F _{nc} 11] 1 to 2	Output logic of upper and lower limit	The logic of the comparator function output. 1: Positive logic 2: Negative logic	1 [P]

6.3.4. Hold Function (H_{ld})

Item Range	Item Name	Descriptions	Default Type
[H _{ld} 1] 0.00 to 9.99	Average time	Time to calculate the average. [sec.] 0.00 : Not used	0.00 [D]
[H _{ld} 2] 0.00 to 9.99	Start wait time	Time to wait before commencing hold or averaging. [sec.]	0.00 [D]
[H _{ld} 3] 0 to 2	Condition of automatic start	Condition for starting the hold or averaging. 0: Not used 2: Above the near-zero range 1: Above the near-zero range, and stable	0 [P]
[H _{ld} 4] 0 to 1	Release using control input	Release when control input is falling. 0: Do not release 1: Release	1 [P]
[H _{ld} 5] 0.00 to 9.99	Release time	Release after a set amount of time has passed. [sec.] 0.00 : Continue	0.00 [D]
[H _{ld} 6] 0 to 99999	Release using fluctuation range	Release when fluctuation from the holding value exceeds a set value. Decimal point depends on [L _{nr} 0]. 0 : Continue	0 [D]
[H _{ld} 7] 0 to 1	Release at near-zero	Release when the weighing value is in the near-zero range. 0: Do not release. 1: Release.	0 [P]

6.3.5. BCD Output Function (B_{cd})

Item Range	Item Name	Descriptions	Default Type
[B _{cd} 1] 1 to 4	Data outputting	1: Weighing value 3: Net weight 2: Gross weight 4: Data specified at BCD input	1 [P]
[B _{cd} 2] 1 to 3	Data transfer mode	1: Stream 3: Manual printing 2: Automatic printing	1 [P]
[B _{cd} 3] 5 to 1000	Data transfer rate	5 times/sec. 10 times/sec. (Depends on [F _{nc} 03]) 20 times/sec. 100 times/sec. 1000 times/sec.	20 [P]
[B _{cd} 4] 1 to 2	Output logic of data transfer	1: Negative logic 2: Positive logic	2 [P]
[B _{cd} 5] 1 to 2	Output logic of negative sign	1: Negative logic 2: Positive logic	2 [P]
[B _{cd} 6] 1 to 2	Output logic of status	1: Negative logic 2: Positive logic	2 [P]
[B _{cd} 7] 1 to 2	Output logic of strobe	1: Negative logic 2: Positive logic	2 [P]
[B _{cd} 8] 0 to 5	Input selection	0: None 1: Clear zero 2: Clear tare 3: Changing between gross and net 4: Print command 5: [F] key	3 [P]
[B _{cd} 9] 0 to 12	Output selection	0: None 1: Stabilization 2: During tare 3: Zero band 4: Hold busy state 5: HI output (Over upper limit) 6: OK output (Within upper and lower limits) 7: LO output (Under lower limit) 8: During operating weighing (On) 9: During operating weighing (1 Hz) 10: During operating weighing (50 Hz) 11: Alarm (Zero correction error and tare error) 12: Busy [F] key	1 [P]