EDU Electric Drive Unit

Low-impedance Solenoid-type Fuel Injector Driver



The EDU is a programmable, universal driver for low-impedance solenoid-type fuel injectors.



Highly reliable and repeatable injections

- High capacity power unit enables high-speed magnetization of the injector. This feature enables highly reliable multi-injection and simultaneous injection among multiple cylinders.
- High-speed current measurement and control technology enables high accuracy injection control. (1 μ s resolution)
- Supports multiple injection strategies. Enables high degree of freedom for pilot, pre, main, post or other injections.
- Ideally suited to diesel combustion R&D and injection control algorithm development with high reliability, accuracy and repeatability injection profile.

Can be applied to a variety of applications


- Each channel can be configured for different injection profiles independently, which enables the control of a variety of injectors, even from different manufacturers. No need for new injector drivers to operate different engines.
- Individual injection timing can be controlled independently. This enables the testing of various patterns of injection for control strategy development and comparison.
- 1 EDU can control up to 6 channels (injectors).
- Can be extended to 3 units (total 18 channels) with daisy chain communication.

Easy settings of injection profile and onboard memory

- Injection profiles can be set up easily with profile table.
- Injection profile tables can be stored into flash memory inside the EDU device. Loading injection profile data from flash memory enables fast start up for testing and development.


The technology

A&D's analog technology enables high-speed current measurement and high quality control.




Injection profile setting

(closed-loop current control)







Injection profile (current control) setting parameters

Symbol	Name	Description	Value Range Initial Value		
Α	High Current Upper Limit	Valid during the whole period of Ph. The maximum-current value specified through an entire region. If current exceeds this threshold, an error [HC_ULE] is generated and SW status is changed to "excitation current OFF."			
В	VH High Current Upper Value	Valid during the period of Ph-1 and 2. If excitation current exceeds this value, VH excitation (S1) is turned OFF.			
С	VH High Current Lower Value	Valid during the period of Ph-1 and 2. If excitation current drops below this value, VH excitation (S1) is turned ON.			
D	VB High Current Upper Value	Valid during the period of Ph-1 and 2. If excitation current exceeds this value, VB excitation (S2) is turned OFF.	3.00~ 24.00 9.00A		
E	VB High Current Lower Value	Valid during the period of Ph-1 and 2. If excitation current exceeds this value, VB excitation (S2) is turned ON.	2.00~ 23.00 8.00A		
F	High Current Lower Limit	Valid during the period of Ph-2. Allowable minimum value of wave fluctuation during the retention period of a high current region. If current drops below this threshold, an error [HC_LLE] is generated and SW status is changed to "excitation current OFF."			
G	Low Current Upper Limit	Valid during the period of Ph-4. If the maximum value of wave current fluctuation during the retention period of a low current region exceeds this threshold, an error [LC ULE] is generated and SW status is changed to "excitation current OFF."			
Н	VB Low Current Upper Value	Valid during the period of Ph-3 and 4. If excitation current exceeds this value, VB excitation (S2) is turned OFF.			
1	VB Low Current Lower Value	Valid during the period of Ph-3 and 4. If excitation current drops below this value, VB excitation (S2) is turned ON.			
J	Low Current Lower Limit	Valid during the period of Ph-3 and 4. Allowable minimum value of wave fluctuation during the retention period of a low current region. If current drops below this threshold, an error [LC LLE] is generated and SW status is changed to "excitation current OFF."			
K	OFF Current Upper Limit	Valid during the period of Ph-O. Allowable-current value when setting excitation current to OFF. If current exceeds than this threshold, an error [operationality criterion ULE] is generated and SW status is changed to "excitation current OFF."			
T1	Rise Time Lower Limit	Since the rate of current value change is too large if the rising period (Ph-1) of excitation current is shorter than this, an error [RT_LLE] is generated and SW status is changed to "excitation current OFF."			
T2	Rise Time Upper Limit	Since the rate of a current value change is too small if the rising period (Ph-1) of excitation current is longer than this, an error [RT_ULE] is generated and SW status is changed to "excitation current OFF."			
ТЗ	High Current Interval Time	A period excited with high current. If it exceeds this time, the sequence shifts directly to Ph-3.			
T4	OFF Current Interval Time	During this time SW status changes to Excitation OFF. Excitation current becomes zero in this period. (Set it to take the value of an AD zero sampling.)			
TII	Injection Time Lower Limit	Warning [IT_LLW] is generated if an injection instruction signal is less than this time.			
T12	Injection Time Upper Limit	If an injection instruction signal exceeds this time, injection behavior is stopped directly and a warning [IT_ULW] is generated.			
T13	Injection Interval Lower Limit	If an injection indication signal time interval is less than this time, warning [IBM PCN II_LLW] is generated.			
T14	Injection Interval Upper Limit	If an injection indication signal time interval exceeds this time, warning [IBM PCN II_ULW] is generated.			

EDU specifications			EDU 1x series		EDU 2x series		
Model name ▶		AD5452-EDU10	AD5452-EDU11	AD5452-EDU20	AD5452-EDU21	AD5452-EDU22	
Power supply		12V		24V			
(Input voltage range)			(+8V~-	+18V)*1	(+16V~+36V)		
Non-destructive input voltage			−32V~+42V				
Maximum input current		20A					
VBD		Main chassis supply					
Power	er VHD		Main chassis supply	Internal high voltage supply Configurable range : 50V~110V	Main chassis supply	Internal high voltage supply Configurable range : 50V~110V	Internal high voltage supply Configurable range : 80V~140V
		Power Consumption	TYP:5W MAX:6W				
		Standby current	Less than 10mA				
Battery	Control unit	Input Impedance	More than $10k\Omega$ (in case of switching to remote mode (RMT)) More than $1M\Omega$ (except switching to remote mode (RMT)			to remote mode (RMT)	
Input		Remote control function	Standard				
		Input		Over current fuse protected			
	Driver	Input	Over current fuse protected				
	Capacity			50~100W*5		50~1	OOW*5
	Outp	ut voltage		50~110V		50~110V	80~140V
	Resolution			Less than 0.1V		Less th	an 0.1V
	Accuracy			±5% of F.S*4		±5% of F.S*4	
VH_	Output Maximum Current			100A*2		100A*2	
Power	Libbie			Less than 500mVp-p*6		Less than 500mVp-p*6	
Output	Input			Over-current fuse protected		Over-current fuse protected	
	Output over-current protection mechanism			1.6A/250µs		1.6A/250 <i>µ</i> s	
	Overhea	t protection mechanism		Standard		Standard	

Injector Driver


System		Current control	
Number of	channels	6 channels	
Injection co	ontrol signal	1 line / channel	
VH output	current	Less than 22A*7	
	Measurement range	0~45A	
Current	Measurement accuracy	±2% of F.S.	
detection	AD resolution	10 bit	
	Sampling frequency	1.25MHz	

General specifications

CPU	RENESAS SH-2 (SH7055F) processor		
Communication method	Ethernet		
Communication device	LANTRONIX X-Port		
Temperature range	-20~70℃ (non-condensing)*3		
Size	250mm(W)×254mm(D)×73.5mm(H)		
Weight	5kg		

- *1 Active only in cranking; 10~18V in normal mode
 *2 Pulse range 100µs intermittent, voltage change less than 5V.
 *3 For >45°C, output current derating is necessary.
 *4 in case of no load.
 *5 Depends on output voltage configuration.
 *6 Range 20MHz and 25°C.
 *7 in case of the following current wave.







For proper use, read the instruction manuals carefully before use.



Clearly a Better Value

A&D Company, Limited 3-23-14 Higashi Ikebukuro Toshima Ku, Tokyo 170-0013 JAPAN Telephone:[81](3) 5391-6132 Fax:[81](3) 5391-6148 http://www.aandd.jp

A&D Technology, Inc. 4622 Runway Blvd. Ann Arbor, MI 48108 U.S.A Telephone:[1](734) 973-1111 Fax:[1](734) 973-1103 http://www.aanddtech.com

A&D Instruments, Ltd.

Unit 24/26 Blacklands Way Abingdon Business Park, Abingdon, Oxon OX14 1DY UNITED KINGDOM Telephone:[44](1235) 550420 Fax:[44](1235) 550485

A&D Technology Trading (Shanghai) Co., Ltd. Room 101, No.1 Fu Hai Business Building, No. 289, Zhang Jiang Bi Sheng Road, Shanghai 201204, CHINA Telephone:[86](21) 3393-2340 Fax:[86](21) 3393-2347

A&D Europe GmbH

Im Leuschnerpark 4, D-64347 Griesheim, GERMANY Telephone:[49](6155) 605 227 Fax:[49](6155) 605 100