Specifications

		Specification				
		Passenger Car (PC)	Truck and Bus (TB)			
Measurement/Control range	Tire load force	10 to 15000 N	50 to 60000 N			
	Inflation pressure	10 to 400 kPa	100 to 1000 kPa			
	Drum surface speed	5 to 120 km/h / to	270 km/h (option)			
	Spindle force (Rolling resistance)	±300 N	±500 N			
	Tire stand stroke*1	200 to 500 mm	300 to 760 mm			
	Tire stand	1 position / 2 p	osition (option)			
Instrumentation accuracy	Tire load force	±10 N	±30 N			
	Inflation pressure	±1 kPa				
	Spindle force	±0.3 N	±0.5 N			
	Distance (Tire axis to the drum surface)	±0.5 mm				
	Temperature sensor	±0.2℃				
	Drum surface speed	±0.05 km/h				
	Time	±0.00	1 sec			
Control accuracy	Tire load force	±20 N	±45 N			
	Inflation pressure	±3 kPa				
	Drum surface speed	±0.2	km/h			
Test tire	Tire diameter	φ 500 to 900	φ 700 to 1500			
	Rim size	12" to 24"	18" to 24"			
	Tire weight	60 kg	160 kg			
Tire stand alignment	Load application	≦1 mrad	(≦0.057°)			
	Camber angle	≦2 mrad (≦0.114°)				
	Slip angle	≦1 mrad (≦0.057°)				
Drum	Diameter	2.0 m / 1.7 m (option)				
	Width	600 mm				
	Frame material	Aluminum / Steel (option)				
Test surface roughness (Drum)	Surface roughness	6.3	3 S			
	Surface material	Stainless stee	I (SUS420J2)			
Measurement reproduciability (σ)	Rolling resistance coefficient	≦0.05 N/kN*2	≦0.06 N/kN*2			
Measurement point	Ambient temperature	0.6 m from the cent	er line of drum width			
Installation requirement	Installation environment temperature	5 to 35°C				
	Floor weight capacity	2000 kg/m² (aluminum cast drum)	2500 kg/m² (aluminum cast drur			
Utility	Power supply	AC380 to 460 V ±10% 50/60 Hz ±5% 120 kVA* ³	AC380 to 460 V ±10% 50/60 Hz ±5% 180 kVA*3			
	Air		n 0.5 MPa			
Size	Main body	W:4220 mm D:1600 mm H:2900 mm	W:4420 mm D:1600 mm H:3000 mm			
	Motor cabinet	W:1800 mm D:600 mm H:2350 mm				
	Operating cabinet	W:570 mm D:80	0 mm H:1887 mm			
Other	Options	Constant temperature chamber				
		Calibration device				

^{*1} Distance from the roller surface to the center of tire rotation.



Safety Warning!

•For proper use, read the instruction manuals carefully before use.

learly a Better Value A&D Company, Limited

3-23-14 Higashi Ikebukuro Toshima Ku, Tokyo 170-0013 JAPAN Telephone:[81](3) 5391-6132 Fax:[81](3) 5391-6148

A&D Technology, Inc. 4622 Runway BNd, Ann Arbor, MI 48108 U.S.A Telephone:[1](734) 973-1111 Fax:[1](734) 973-1103 http://www.aanddtech.com

A&D Instruments, Ltd.

Unit 24/26 Blacklands Way Abingdon Business Park, Abingdon, Oxon OX14 1DY UNITED KINGDOM Telephone:[44](1235) 550420 Fax:[44](1235) 550485

A&D Technology Trading (Shanghai) Co., Ltd. Room 101, No.1 Fu Hai Business Building, No. 289, Zhang Jiang Bi Sheng Road, Shanghai 201204, CHINA Telephone:(86)(21) 3393-2340 Fax:(86)(21) 3393-2347

A&D Europe GmbH Im Leuschnerpark 4, D-64347 Griesheim, GERMANY Telephone:[49](6155) 605 250 Fax:[49](6155) 605 100

A&D Australasia Pty Ltd.

32 Dew Street, Thebarton, South Australia 5031 AUSTRALIA Telephone:[61](8) 8301-8100 Fax:[61](8) 8352-7409


A&D KOREA Limited

Manhattan Bldg, 8F, 36-2 Yoido-dong, Youngdeunggo-gu, Seoul, KOREA Telephone:[82](2) 780-4101 Fax:[82](2) 782-4280

• Appearances and/or specifications subject to change for improvement without notice, Contents of this catalog last updated September 2011.

*RRTR-ADCC-01-BP1-11901

Tire Rolling Resistance Test Rig



^{*2} Standard deviation of three consecutive tests is the reproducibility value. The temperature variation for the three tests must be within ±1°C. If the environment temperature cannot be controlled to meet this requirement, we offer a constant temperature chamber as an option. Please feel free to contact us when this option is necessary



Features

High accuracy and robust measurement

Rolling resistance: PC \leq ±0.3 N TB \leq ±0.5 N Measurement reproducibility: $\sigma \leq$ 0.05 N/KN

- Test standards compliance
- Fully automated
- Energy saving from aluminum cast drum

High accuracy and robust measurement

■ Model Based Sensor (MBS)

The core component for measuring rolling resistance uses A&D's in-house measurement technology with a digital sensor, which minimizes cross-talk error and measures 6 components of force with high accuracy.

■Temperature monitoring and compensation

Three temperature sensors are installed in the system to monitor atmosphere, tire surface, and drum surface temperature. In addition, 6 components of force are digitally measured, and then optimal temperature compensation is applied to achieve the ideal measurement. A temperature chamber option is also available.

■ Highly rigid design

The drum and tire stands are designed to have high rigidity for precise tire alignment and measurement, which results in a high measurement reproducibility with $\sigma \le 0.05$ N/kN. This enables an optimized sample check for tire lots.

Test standards compliance

- ■The testing system supports international test standards required for tire testing. Standards include ISO 28580.
- All the test sequences are pre-programmed and fully automated.


Fully automated testing

- ■In addition to standards tests, user specific test patterns can also be programmed.
- ■Up to 20 different test patterns can be scheduled.
- ■Test data including test condition information is saved in CSV format for flexible usage.


Energy savings from the aluminum cast drum

- ■A&D introduced the world's first test drum using an aluminum cast drum.
- ■The aluminum cast drum reduces the inertia of the drum by almost half.

 Compared to a steel drum, system operating energy is reduced by 30%. (According to in-house testing)



6 components sensor



Main window



Drum

Measurement data

Measurement data with a standard tire.

	[Calculation			Measurement					Skim test measurement							
	Rotation direction	RR	RR temp. correct	RRC	Spindle force	Tire load	Distance (Drum surface- tyre axis)	Ambient temperature	Tire surface temperature	Drum surface temperature	Drum speed	Spindle force	Tire load	Distance Drum surface- tyre axis)	Parasitio loss		
		[N]	[N] [N]	[N]] [N]	[N/kN]	[N]	[N]	[mm]	[%]	[%]	[%]	[km/h]	[N]	[N]	[mm]	[N]
	Normal	30.21	30.42	7.12	27.48	4272	286.87	25.9	28.8	26.4	80.02	3.94	100	308.50	5.15		
1	Reverse	30.64	30.98	7.25	27.49	4272	286.84	26.4	28.6	26.0	80.02	3.61	100	308.54	4.73		
2	Normal	30.69	30.71	7.19	27.78	4272	286.95	25.1	28.4	26.0	80.02	3.86	100	308.53	5.06		
	Reverse	30.78	30.87	7.23	27.55	4272	286.96	25.4	28.2	25.7	80.03	3.58	100	308.57	4.68		
3	Normal	30.67	30.64	7.17	27.81	4272	287.06	24.9	27.6	25.1	80.03	3.91	100	308.56	5.12		
	Reverse	30.77	30.69	7.18	27.62	4272	287.02	24.7	27.8	25.3	80.03	3.65	100	308.58	4.78		

RRC repeatability

	1	2	3	Ave.	σ
Normal	7.12	7.19	7.17	7.16	0.035
Reverse	7.25	7.23	7.18	7.22	0.034
Average	7.19	7.21	7.18	7.19	0.015

Test tire information


 Size & specifications
 195/55R16 87V

 RR (Data sheet)
 30.8 [N]

 RRC (Data sheet)
 7.21 [N/kN]

Calibration device

A&D is well versed in force measurements and offers a high-quality calibration device that has been manufactured in-house for calibrating the system on site. The calibration device is available as an option and the user can calibrate the system themselves for easy maintenance, or an A&D engineer can visit the user's site for periodical calibration service.





Layout options

When installing the testing machine, space may be limited. However, the position of driving motor can be selected, which provides flexibility when installing the testing machine.

